

Small 90503 Solenoid repair



Drill 2 small holes approx 3,5-4mm as shown on picture.



Spray CRC 556, WD40 or simimilar in holes like shown. Both sides.

If you want to seal holes, use some tape over the holes, but not nessesary.



Solenoid should be mounted on a dry place.
Do not mount the solenoid inside the anchor locker.