

Gypsy adjustment 6mm DIN766



Problem chain jamming in windlass.



Remove gypsy from windlass.



Use a angle grinder with sand paper disk.



Sand down chain tooth corner like shown on picture.